

# SUMMIT HILL®

## Louver Protrusion for Interior Shutters

The following chart can be used to determine if you have enough depth for an inside mount.

<u>Shutter thickness</u>	<u>Louver Size</u>	<u>Depth required*</u>	<u>Add for Summit View</u>
3/4"	1-1/4"	1-3/8"	N/A
3/4"	1-3/4"	1-5/8"	5/16"
3/4"	2-1/2"	1-7/8"	5/16"
3/4"	3-1/2"	2-3/8"	5/16"
1-1/8"	2-1/2"	1-15/16"	3/8"
1-1/8"	3-1/2"	2-7/16"	3/8"
1-1/8"	4-1/2"	2-15/16"	3/8"
1-1/8"	5-1/2"	3-7/16"	N/A

\*Includes 1/8" extra for clearance.