



# SUMMIT HILL®

## Shutter Configurations For All Shutter Lines


### SHUTTERS WITH DIVIDER RAIL




1 panel



2 panels



3 panels




4 panels


### SHUTTERS WITHOUT DIVIDER RAIL (DOUBLE HUNG)



1 over 1



2 over 2



3 over 3




4 over 4


### SHUTTERS WITHOUT DIVIDER RAIL




1 panel



2 panels



3 panels




4 panels


### CAFE STYLE SHUTTERS




1 café panel



2 café panels



3 café panels



4 café panels